

MINIMEX
SUPER BLEND 2
HEAVY DUTY PROFESSIONAL BLENDER

จัดจำหน่ายโดย

บริษัท เพ็น เค อินเตอร์เทรดดิ้ง จำกัด

อาคาร พี.บี. ทาวเวอร์ ชั้นที่ 16 เลขที่ 1000/63-64
ถนนสุขุมวิท 71 แขวงคลองตันเหนือ เขตวัฒนา กรุงเทพฯ 10110

เบอร์โทร 02-391-0919 แฟกซ์ 02-391-1141

ศูนย์บริการ minimex 02-817-8999

MINIMEX
SUPER BLEND 2
HEAVY DUTY PROFESSIONAL BLENDER



คู่มือการใช้งาน
เครื่องปั่นน้ำผลไม้

Minimex
รุ่น Super Blend2
(MCB1-2)

Instruction Manual
Minimex Super Blender

Model: MCB1-2

220-240V., ~50Hz., 2,238W.

ไทย / English

WARRANTY

We hereby warranty Minimex High Speed Nutrition Blender model Super Blend2 (MCB1-2) as follow :

Motor 2 (two) year.

Other parts 1(one) year.

*This warranty is not cover general wears and tears of **blade** and **drive coupler** .

Warranty Conditions

The warranty cover product defective and workmanship .

User must use in a properly manner and follow the instructions manual.

Warranty exceptions

We disclaims all responsibility for incidental or consequential damage caused by use of this appliance This warranty will be void if customers.

- lead to a misunderstanding of the purpose of the design, such as using product in a commercial use.
- Use the wrong way or not used as described in the instruction manual.
- no maintenance as recommended in the instruction manual.

Customer right for product warranty

The warranty is effective on the date specified in the warranty card , invoice or receipt as proof of purchase. Failure of product to the warranty.

Determination of defective product

The company will inspect the false or defective product and decide that the defective of the product is in warranty or not. The decision is solely the rights of the company. If the defective is covered by warranty company will be responsible for parts and labor to repair and deliver the product to customers' house. Customers do not have to pay any fee.

If the company considers that it must change its products to customers, but the same model of product is not available, the company will determine an appropriate version of the product to be replaced.

Returns of Product

If customer purchases to be dissatisfy. Customer could return the product within 15 days after purchasing date only if the product is completely perfect packaging and has not been used before. Customers must present proof of purchase to return the product at the store of purchase only.

Service Center

If customer need service or information, customer can contact our Minimex Service Center phone number:02-817-8999.

ส่วนประกอบ



ก่อนการใช้งาน

1. ตรวจสอบปลั๊กออกกลางด้วยน้ำยาล้างจาน แล้วเช็ดให้แห้ง นำโถวางบนฐานมอเตอร์
2. เสียบปลั๊กต่อเครื่องเข้ากับเต้าเสียบไฟบ้าน
3. สวิตช์เปิด – ปิด ออกแบบให้ใช้งาน โยกขึ้น เปิด (ON) โยกลง ปิด (OFF)
4. สวิตช์ปรับความเร็ว มี 2 ระดับ ช้า (Low) เร็ว (High)

การใช้งาน

1. วางเครื่องบนพื้นที่ราบและแห้ง
2. ห้ามเปิดเครื่องในสภาพโถว่างเปล่า
3. ห้ามยกหรือเปลี่ยนสถานะเครื่องกำลังทำงาน
4. ห้ามเปิดเครื่องโดยไม่วางโถให้เรียบร้อย
5. เช็ดฐานรองโถให้แห้งตลอดเวลา อย่าปล่อยให้เปียก เพราะความชื้นอาจทำให้เกิดความเสียหายแก่มอเตอร์ได้
6. การวางโถลงบนฐานรองโถ ควรตรวจสอบให้แน่ใจว่าแกนใบมีดสอดเข้าในเบ้าป็น (แกนมอเตอร์) อย่างสนิทแล้ว
7. ใบมีด มีการหมุนในรูปสูงมาก สูงกว่าเครื่องปั่นทั่วไป การใช้ปั่นที่นานกว่าปกติ จะทำให้เกิดความร้อน และจะทำให้อาหารที่ปั่นร้อนไปด้วย
8. หากเครื่องติดยังไม่ถูกปั่นจนทั่ว ขอแนะนำให้ใช้ ปุ่ม HI/LOW เพื่อช่วยให้เครื่องติดยกปั่นเข้ากันได้ดียิ่งขึ้น หรืออาจใช้เวลาปั่นที่ยาวนานขึ้น
9. ควรใส่น้ำหรือของเหลวร่วมกับการปั่นน้ำแข็งก่อนเสมอ

การทำความสะอาด

ควรถอดปลั๊กก่อนเพื่อความปลอดภัย

1. ใส่น้ำอุ่นลงในโถพอประมาณ ให้ท่วมใบมีด แล้วใส่น้ำยาล้างจานลงไปเล็กน้อย ปิดฝาโถให้เรียบร้อย แล้วเปิดสวิตช์ให้ใบมีดปั่นเป็นเวลาประมาณ 10 วินาที โดยวิธีนี้จะทำให้สิ่งสกปรกถูกล้างออก ล้างโถด้วยน้ำสะอาดแล้วเช็ดให้แห้ง
2. หากต้องการเปลี่ยนใบมีด ให้ถอดใบมีดออกโดยหมุนวงแหวนเกลียวล็อกใบมีดได้โถ ตามเข็มนาฬิกา
3. การทำความสะอาดฐาน ฐานรองโถและฐานมอเตอร์ ควรใช้ผ้าชุบน้ำบิดหมาด เช็ดให้สะอาด ห้ามจุ่มฐานมอเตอร์ลงในน้ำเด็ดขาด
4. เพื่อยืดอายุกลไกภายในของใบมีด ไม่ควรจุ่มตัวโถลงในน้ำหรือแช่น้ำเป็นเวลานาน การระมัดระวังนี้ จะช่วยทำให้ระบบหล่อลื่นใบมีดมีอายุใช้งานยาวนานขึ้น

TROUBLESHOOTING

Warning: Unplug the power cord to ensure safety .

1. This blender is fitted with a safety overload switch at the bottom of the machine. If the motor overloads, the power will be automatically cut to ensure safety. Please check and remove unsuitable blending ingredients, then press the reset button (on the bottom) to start again.
2. Ensure that the power cord is correctly connected to the blender.
3. If the blender still does not function correctly, contact and consult your nearest distributor and refer to the warranty card. Do not attempt to disassemble and repair it on your own.
4. If the power cord is damaged, it must be replaced or repaired by a qualified electrician or engineer to avoid hazard.
5. After long-term use, the cutting unit will wear down and require replacement. Contact your store of purchase, nearest distributor, or one of our after-service centers. **Warning: Blades are sharp, handle carefully.**

IMPORTANT SAFEGUARDS

Read all instructions

- To protect against risk of electrical shock, do not place blender base or power supply cord in water or in any other liquid.
- Close supervision is necessary when the appliance is used by or near children.
- Unplug from outlet prior to assembling or cleaning the appliance.
- Avoid touching moving parts.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner.
- Return appliance to nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.
- Do not use outdoors. This appliance is for indoor use only.
- Do not let cord hang over the edge of the table or counter.
- Keep hands and utensils out of the jug while operating to reduce risk of severe injury or damage. A scraper may be used only when the blender is OFF.
- Blades are sharp. Handle carefully.
- To reduce risk of injury, never place cutting blade assembly on base without ensuring the jug is properly attached; never remove the jug during operation.
- Only operate the blender with the lid in place.
- The manufacturer does not recommend use of attachments, including canning jugs, because these may cause injury.
- Jug should not be more than 2/3 full when blending or when mixing rod is left in place. Mixing rod (tamper tool) must ONLY be used through the hole in the lid when blender is in operation.
- Over-processing will cause the mixture to overheat.
- Ensure the blender on a flat, level, stable and dry surface prior to operation
- Always ensure that the jug is properly seated in position and the jug lid is properly fitted and secured before switching on the blender.
- When blending hot liquids : do not fill jug above the 1-litre mark, leave the lid plug out to allow steam to escape. Always start the motor on LO speed and increase to HI speed if necessary
- Ensure that the lid is located under raised projections on the jug before switching on
- The lid can only be removed when the blender is OFF and the cutting unit has ceased turning.
- Never leave the blender unattended when in use.

QUICK GUIDE

1. Insert the power plug into an electrical outlet.
2. Turn on the main power switch.
3. Properly fill and place the blender jug on the base, making sure the jug fits securely and the lid is tightly attached.
4. Manual operation: select HIGH, LOW, (these selections will cause the blender to blend continuously at the predetermined speed)

OPERATING INSTRUCTIONS

1. Operate blender on a flat, clean, and dry surface.
2. Never operate the blender when the jug is empty.
3. Do not attempt to remove or replace the jug while the motor is running.
4. Never run motor while jug is not in place.
5. Wipe water off of the cushion before operation, Any water present could be pulled in and will cause damage to the motor!
6. Make sure the drive shaft on the jug is fully engaged into the drive socket and that the blade is firmly affixed to the drive shaft.
7. This blender is a high-speed unit. Blending times are much faster than those of other blenders, but extended use will heat up the contents of the blender.
8. If drink has mixed well but not blended completely, press HI/LOW for extra blending time or choose a longer automatic cycle.
9. Always add some liquid to crush ice cubes.

CLEANING

Warning : Unplug the power cord to ensure safety.

1. Place a little warm water with a small amount of detergent into the jug. Attach lid and switch blender on for approximately 10 seconds. This will remove almost all residue. Empty jug, rinse, and leave upturned to dry. Do not clean inside of jug by hand unless cutting unit has been removed.
2. To remove or replace blade assembly, simply turn the retaining ring at the bottom of the jug counter-clockwise.
3. To clean motor base, use a slightly damp cloth only. Never immerse motor base in water.
4. To extend the lifespan of the cutting unit, please do not immerse the jug in water or leave water in the jug for a long period of time. Following this precaution will help to prevent rusting of the ball bearing by reducing its potential contact with water to a minimum.

การแก้ปัญหา

(เมื่อเกิดปัญหาใดๆ ควรถอดปลั๊กไฟออกจากเต้าเสียบไฟบ้าน)

1. เครื่องปั่นนี้มีระบบตัดไฟอัตโนมัติ เมื่อใช้งานหนักเกินกำหนดของมอเตอร์ ทั้งนี้เพื่อความปลอดภัย หากเกิดกรณีดังกล่าวกับการใช้งานของท่าน ควรนำอาหารที่ปั่นออกจากโถปั่นก่อน แล้วกดปุ่ม Reset ได้ฐาน เพื่อให้สามารถกลับมาใช้งานได้ตามปกติอีกครั้งหนึ่ง
2. หากเครื่องหยุดโดยไม่ทราบสาเหตุ ควรตรวจสอบให้แน่ใจว่าสายไฟมีการติดตั้งกับฐานมอเตอร์อย่างถูกต้องสมบูรณ์หรือไม่
3. หากเครื่องหยุดทำงาน และท่านได้ทำการตรวจสอบตามข้อ 1 และ 2 แล้ว ยังไม่สามารถแก้ปัญหาได้ ควรติดต่อศูนย์บริการฯ ไม่ควรซ่อมด้วยตัวเอง หรือช่างที่มีเชื้อจากศูนย์บริการฯ เพราะจะทำให้การรับประกันสิ้นสุดทันที
4. หากพบว่า สายไฟมีรอยฉีกขาดหรือเสียหาย ควรส่งเข้าเปลี่ยนใหม่ ณ ศูนย์บริการฯ โทร. 02-817-8999
5. ชุดใบมีดมีการสึกหรอ หากใช้เวลานาน ควรส่งเข้าศูนย์บริการฯ เพื่อเปลี่ยนใหม่ (ชุดใบมีดมีได้อยู่ในเงื่อนไขของการรับประกัน) (ชุดใบมีดที่เปลี่ยนใหม่มีความคม ควรใช้ด้วยความระมัดระวัง)

คำเตือนเพื่อความปลอดภัย

โปรดอ่านอย่างละเอียด

- เพื่อป้องกันไฟช็อตหรือไฟฟ้าลัดวงจร ห้าม วางตัวเครื่อง หรือสายไฟลงในน้ำหรือของเหลวชนิดอื่น
- หากอนุญาตให้เด็กใช้ควรดูแลอย่างใกล้ชิด
- ถอดปลั๊กไฟออกจากเต้าเสียบไฟบ้านทุกครั้ง ที่ถอดเครื่องหรือทำความสะอาด
- หลีกเลี่ยงการสัมผัสชิ้นส่วนที่มีการเคลื่อนไหว ห้ามใช้มือหย่อนลงไปโถปั่น
- หากเครื่องตกจากที่สูง หรือพบว่ามีการถลอกฉีกขาดของสายไฟ ควรหยุดใช้ทันที แล้วส่งเข้าตรวจสอบ ณ ศูนย์บริการฯ
- การซ่อมหรือบำรุงรักษาต่างๆ ขอแนะนำให้ท่านส่งเข้าศูนย์บริการฯ ของ Minimex เท่านั้น
- เครื่องปั่นนี้ออกแบบให้ใช้ในที่ร่มเท่านั้น ห้ามใช้ในที่โล่งแจ้งอย่างเด็ดขาด
- อย่าให้สายไฟแขวนหรือตรงตามขอบโต๊ะ หรือเต้าเสียบไฟ
- ขณะเครื่องทำงานควรเอาเครื่องใช้ต่างๆ ออกจากโถปั่น เพื่อป้องกันอันตรายร้ายแรงที่อาจเกิดขึ้น การใช้เกรียงชูดอาจทำได้เฉพาะเมื่อขณะเครื่องหยุดเท่านั้น
- ใบมีดมีความแหลมคม ควรใช้ความระมัดระวัง
- เพื่อป้องกันอันตรายที่อาจเกิดขึ้นได้ การประกอบใบมีดลงในโถต้องทำด้วยความระมัดระวัง ห้ามดึงหรือถอดโถปั่นออกขณะเครื่องกำลังทำงาน
- ปิดฝาทุกครั้งที่ใช้งาน
- โรงงานผู้ผลิตไม่แนะนำให้ใช้อุปกรณ์อื่นๆ นอกเหนือจากที่ให้มาพร้อมกับตัวเครื่อง เพราะอาจทำให้เกิดอันตรายได้
- ควรดื่มอาหารหรือน้ำลงในโถไม่เกิน 2/3 ความจุของโถเมื่อใช้ไม้คน การใช้ไม้คนควรสอดไม้คนผ่านช่องของฝาด้านบน
- การดื่มอาหารลงในโถมากเกินไป อาจทำให้ลื่น เสียหาย และเป็นอันตรายได้
- ควรวางเครื่องไว้บนพื้นราบที่มั่นคง และแห้งเท่านั้น
- ตรวจสอบให้แน่ใจว่า ท่านได้วางโถปั่นเข้าที่อย่างสนิทและปิดฝาทันทีให้เรียบร้อย ก่อนเปิดสวิตช์ใช้งาน
- หากปั่นของเหลวร้อน ควรเอาตามคนออก เพื่อให้ไอร้อนสามารถระบายออกจากโถได้
- ตรวจสอบให้แน่ใจว่า ปิดฝาด้อย่างถูกต้อง ไม่กลับด้าน การปิดฝาดหรือถอดออก สามารถทำได้เฉพาะขณะเครื่องปิดเท่านั้น
- อย่าปล่อยเครื่องให้ทำงานโดยปราศจากการดูแล

— เก็บคู่มือนี้ไว้เพื่ออาจใช้ในอนาคต —

การรับประกัน

เครื่องปั่นอาหารความเร็วสูง Minimax รุ่น Super Blend2 (MCB1-2) มีระยะเวลาประกัน

มอเตอร์ 2 ปี

ส่วนประกอบอื่น 1 ปี

***ไม่รวมการสึกหรอของใบมีด และ เฟืองปั่น**

เงื่อนไขการรับประกัน

การรับประกันครอบคลุมคุณภาพของสินค้าและฝีมือการประกอบโดยสินค้าต้องใช้ในครัวเรือนเท่านั้น

ผู้ซื้อต้องใช้งานและบำรุงรักษาอย่างถูกต้องตามคำแนะนำในหนังสือคู่มือ

ข้อยกเว้นการรับประกัน

บริษัทฯ ขอสงวนสิทธิ์ในความรับผิดชอบต่อความเสียหายใดๆ ที่เป็นผลสืบเนื่องจากการใช้สินค้า

และสงวนสิทธิ์การรับประกันหากลูกค้า :

- นำสินค้าไปใช้ผิดจากวัตถุประสงค์ของการออกแบบ เช่น การนำเอาสินค้าที่ออกแบบมาเพื่อการใช้ในครัวเรือนแต่นำไปใช้เพื่อประกอบอาชีพหรือในเชิงพาณิชย์
- ใช้งานผิดวิธีหรือไม่ได้ใช้งานตามวิธีที่อธิบายในหนังสือคู่มือ
- ไม่ได้บำรุงรักษาตามคำแนะนำในหนังสือคู่มือ

การใช้สิทธิ์การรับประกันสินค้า

การรับประกันสินค้ามีผลตามวันที่ ที่ระบุในใบรับประกันสินค้า กรุณาแสดงใบรับประกันสินค้าหรือใบกำกับภาษีใบเสร็จรับเงิน เพื่อเป็นหลักฐานในการติดต่อเจ้าหน้าที่ศูนย์บริการฯ ในการใช้สิทธิ์การรับประกันสินค้า

การพิจารณาความบกพร่องของสินค้าเพื่อการรับประกัน

บริษัทฯ จะทำการตรวจสอบสินค้าอย่างละเอียด และตัดสินใจว่า ความบกพร่องของสินค้านั้นอยู่ในเงื่อนไข

การรับประกันหรือไม่ซึ่งเป็นสิทธิ์ของบริษัทฯ เท่านั้น ในกรณีที่อยู่ในเงื่อนไขการรับประกัน บริษัทฯ

จะเป็นผู้รับผิดชอบค่าแรงในการซ่อม ค่าอะไหล่ และค่าจัดส่งสินค้าถึงบ้านลูกค้า โดยลูกค้าไม่ต้องชำระค่า

บริการใดๆ ทั้งสิ้นหาก บริษัทฯ พิจารณาเห็นว่าต้องเปลี่ยนสินค้าใหม่ให้แก่ลูกค้าแต่สินค้ารุ่นเดียวกันไม่มี

จำหน่ายแล้ว บริษัทฯ จะเป็นผู้ตัดสินใจว่าสินค้านั้นใดเหมาะสมที่จะเปลี่ยนแทน

การคืนสินค้า

ในกรณีที่ลูกค้าซื้อสินค้าไปแล้วแต่ไม่พอใจ บริษัทฯ ยินดีรับคืนสินค้าภายใน 15 วัน โดยมีเงื่อนไขว่าสินค้าต้องมีบรรจุภัณฑ์อย่างสมบูรณ์และสินค้ามิได้ถูกใช้งานมาก่อน โดยลูกค้าต้องนำหลักฐานการซื้อเพื่อคืนสินค้า ณ ร้านค้าที่ซื้อเท่านั้น

ศูนย์บริการ

หากท่านต้องการบริการหรือรายละเอียดเพิ่มเติมท่านสามารถติดต่อศูนย์บริการได้ โทร .02 817-8999

PARTS & FUNCTIONS

